

# How to measure guide



Sliding doors fitted to Trend® Synergy® and Quantum® FXX stacking doors (Post Nov 2016)

To ensure the Prowler Proof security screen doors you are ordering fit and perform perfectly, please follow the steps below. All doors should be ordered as make size. Please note all references should be taken from outside view looking in.

**1 Drop**

**Left:** \_\_\_\_\_ mm  
Subtract 12mm  
= \_\_\_\_\_ mm

**Right:** \_\_\_\_\_ mm  
Subtract 12mm  
= \_\_\_\_\_ mm

**Note:** Use smallest size for door opening size when ordering. Both screen doors will be this height.

**4 Optional bolts** (\*additional costs)

**Required**  Yes  No

**Select Type**  Flush bolt  Patio bolt

**Position leading edge inactive leaf**

Top  Bottom

**2 Interlock lengths**

Use your door opening size (A) and subtract interlock clearance of 45mm: \_\_\_\_\_ mm

**5 Lock height**

The security door's handle can be above or below the existing door's lock/handle.

**Above:** Measure from jamb to top of existing door's lock/handle: \_\_\_\_\_ mm  
Add 25mm = \_\_\_\_\_ mm

**Below:** Measure from jamb to bottom of existing door's lock/handle: \_\_\_\_\_ mm  
Subtract 185mm = \_\_\_\_\_ mm

**Note:** Select one position only.

**3 Width**

**Top:** \_\_\_\_\_ mm  
Add 92mm, then divide by 2: \_\_\_\_\_ mm

**Middle:** \_\_\_\_\_ mm  
Add 92mm, then divide by 2: \_\_\_\_\_ mm

**Bottom:** \_\_\_\_\_ mm  
Add 92mm, then divide by 2: \_\_\_\_\_ mm

**Note:** Both screen doors will be this width.

**6 Handle side**

**Left Hand Side**  **Right Hand Side**

From the outside looking in, which side should the handle be on the door?  Left

**Note:** Usually the same side as the handle on the existing door.  Right

**Customer details**

Customer name	
Contact number	
Address	